







Inleiding


De Maxi-Cosi houder is ontworpen om een kind in een Maxi-Cosi veilig te vervoeren in de Bakfiets.nl. De Maxi-Cosi kan makkelijk in de houder worden gemonteerd, zonder dat het kind uit de Maxi-Cosi hoeft te worden gehaald. De houder wordt standaard geleverd met makkelijk verwijderbare bouten, waardoor de houder snel te verwijderen is. Om de houder inclusief Maxi-Cosi makkelijk te verwijderen, is er een Quick Release systeem verkrijgbaar via uw dealer.



Het monteren van de houder.



Stap 1: Assembleer de Maxi-Cosi houder zoals hiernaast afgebeeld. De bouten kunnen los-vast gemonteerd worden. Na het definitief bepalen van de positie alle bouten goed vastzetten.






Stap 2: Monteer de Maxi-Cosi in de houder en zoek de beste plek in de bak. **Let op**: Maxi-Cosi's zijn er in verschillende afmetingen. Gebruik de Maxi-Cosi die gebruikt gaat worden om de plaatst te bepalen. Houd rekening met de veerweg en indien van toepassing de tent.

Stap 3: Controleer de positie nogmaals en markeer de locatie van de gaten. Houdt ook rekening mee dat de metalen strip gemonteerd kan worden aan de onderzijde van de bak. Gebruik een boor om de gaten te boren (6,5mm voor de standaard bouten & 12,5mm voor het Quick Release systeem).
TIP: Plaats een blok hout achter het te boren gat om splijten van het hout te voorkomen.





Stap 4: Assembleer de bouten en monteer de houder met de metalen strip onder de bak. Boor de gaten voor en monteer met de bijgeleverde schroeven.
Later upgraden naar Quick Release? Verwijder de metalen strip van de onderzijde van de bak en boor de gaten op naar 12,5mm. Monteer vervolgens de metalen strip 180 graden gedraaid terug (in dezelfde gaten).








Introduction


The Maxi-Cosi holder is designed to safely transport a child in a Maxi-Cosi in the Bakfiets.nl. The Maxi-Cosi can be easily mounted in the holder without having to remove the child out of the Maxi-Cosi. The holder comes standard with easily removable bolts, allowing for quick removal. To easily remove the holder along with the Maxi-Cosi, a Quick Release system is available through your dealer.



Mounting the holder.



Step 1: Assemble the Maxi-Cosi holder like shown in the picture beside. The bolts can be mounted loose-fast. After final positioning, tighten all bolts securely.





Step 2: Mount the Maxi-Cosi in the holder and find the best place in the box. **Please note:** Maxi-Cosi seats come in different sizes. Use the specific Maxi-Cosi you plan to use to determine the placement. Take into consideration the suspension travel and, if applicable, the tent.

Step 3: Check the position again and mark the location of the holes. Please also note that the metal strip can be mounted on the underside of the box. Use a drill to drill the holes (6.5 mm for the standard bolts and 12.5 mm for the Quick Release system).
TIP: Place a block of wood behind the hole to be drilled to avoid splintering the wood.





Step 4: Assemble the bolts and mount the holder with the metal strip underneath the box. Pre-drill the holes and assemble with the screws provided.
Upgrading to Quick Release later? Remove the metal strip from the bottom of the box and enlarge the holes to 12.5 mm. Then reinstall the metal strip rotated 180 degrees (in the same holes).